



The Indoor Orca Cam Installation Instructions

Step 1: Remove camera unit from packaging and inspect for any damage that may have occurred during shipping. If there is damage please take photos and contact us at 1-833-ORCA-IOT (672-2468). Be sure to keep the original packaging for return when the project is completed.

Step 2: You will have an included wall mount. Screw the wall mount into the wall or wood. If using wood screws, make sure and use structural washers so the heads don't slip through. If you are mounting it in drywall, please use anchors.

Tip: *The mount is 2 pieces. Take it apart and attach the base to the camera separate from the mount arm on the wall. It makes it easier doing it on the ground vs on the wall.*

Step 3: Loosen the fasteners on the side and bottom to rotate and aim it. The camera lens is wide angle and captures 102 degrees.

Step 4: Plug it in.

Step 5: Clean Up. Zip tie the cables to the wall mount and ideally down the wire.

Step 6: Call us at 1 833 ORCA IOT to finish aiming and online the camera.

If you already have an account, you can view images at <https://platform.orcaiot.com>

Thank you

WARNING: *Keep the custom packaging for return or we will charge \$75 to mail new packaging. If we receive any parts in non-Orca packaging, we will assess a \$99 inspection fee plus damages. We are not doing this to nickel and dime you. 9 out of 10 shipments without original packaging arrive broken.*

Orca IoT

1827 Powers Ferry Rd,
STE 10-100,
Atlanta, GA 30339

www.orcaiot.com

1 (833) ORCA IOT